

SPARE PARTS LIST

MODEL NO. MT230

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	JM23000001	GRIP	1	
002	JM23000002	HANDLE BRACKET	1	
003	JM23000003	SPRING WASHER8	2	
004	JM23000004	HEX. SOCKET HEAD BOLT M8 X 20	2	
005	*****	*****	***	*****
006	JM23000006	LOCK KNOB FOR EXT.WINGS	2	
007	JM23000007	MITER ANGLE LABEL	1	
008	JM23000008	RIVET	2	
009	JM23000009	BASE COMP INC. 7,8,10	1	
010	810965-6	CAUTIONLABEL	1	
011	JM23000011	BASE SUPPORTER	1	
012	JM23000012	SCREW	1	
013	JM23000013	FLAT WASHER10	2	
014	JM23000014	SADDLE SHAPE WASHER	1	
015	JM23000015	ANTI-LOOSE NUTM10	1	
016	JM23000016	SLIDE PLATE	2	
017	JM23000017	MITER ANGLE POINTER	1	
018	JM23000018	COUNTERSUNK HEAD SCREW M4X10	5	
019	JM23000019	PIVOT	1	
020	JM23000020	KERF BOARD	1	
021	JM23000021	TURN BASE COMP.	1	
022	JM23000022	PROTECTION NET	1	
023	*****	*****	***	*****
024	JM23000024	HEX.BOLT M8X30	4	
025	JM23000003	SPRING WASHER8	4	
026	JM23000026	FLAT WASHER8	4	
027	JM23000027	HEX. BOLT M8 X 20	2	
028	JM23000028	HEX. NUT M8	2	
029	JM23000029	BEVEL POINTER	1	
030	JM23000030	FLAT WASHER5	1	
031	JM23000031	SPRING WASHER5	1	
032	JM23000032	PAN HEAD SCREW M5 X 10	1	
033	JM23000033	HEX. BOLT M8X16	1	
034	JM23000028	HEX. NUT M8	1	
035	JM23000034	RIVET	2	
036	JM23000035	SCALE LABEL	1	
037	JM23000036	ARM COMPLETE INC. 35,36	1	
038	JM23000037	SHAFT	1	
039	JM23000038	LINK SUPPORT PLATE	1	
040	JM23000039	PAN HEAD SCREW M6 X 16	3	
041	JM23000040	SPRING WASHER6	3	
042	JM23000041	FLAT WASHER6	3	
043	JM23000042	CLIP	1	
044	JM23000030	FLAT WASHER5	1	
045	JM23000031	SPRING WASHER5	1	
046	JM23000032	PAN HEAD SCREW M5 X 10	1	
047	JM23000043	KNOB	1	
048	JM23000013	FLAT WASHER10	1	
049	JM23000044	ANTI-LOOSE NUTM12	1	
050	JM23000045	FLAT WASHER12	1	
051	JM23000046	LOCK PIN CAP	1	
052	JM23000047	O RING	1	
053	JM23000048	PIN	1	
054	JM23000049	LIMIT PIN	1	
055	JM23000050	TORSIONAL SPRING	1	
056	JM23000051	RING	1	
057	JM23000052	HEX. SOCKET HEAD BOLT M6 X 20	4	
058	JM23000040	SPRING WASHER6	4	
059	JM23000041	FLAT WASHER6	4	

SPARE PARTS LIST

MODEL NO. MT230

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
060	JM23000030	FLAT WASHER5	2	
061	JM23000031	SPRING WASHER5	2	
062	JM23000032	PAN HEAD SCREW M5 X 10	2	
063	JM23000053	PLATE	1	
064	JM23000054	BLADE LOCK BOLT	1	
065	JM23000055	STEPPED BOLT M5	1	
066	JM23000056	BUSH	1	
067	JM23000057	STEPPED BOLT M6	1	
068	JM23000058	LINK COMP.	1	
069	*****	*****	***	*****
070	*****	*****	***	*****
071	*****	*****	***	*****
072	JM23080001	MAKTEC LABEL	1	
073	817667-5	CAUTIONLABEL	1	
074	810968-0	CAUTIONLABEL	1	
075	JM23000063	LIMIT RING	1	
076	JM23000064	SCREW	1	
077	JM23000065	FLANGE	2	
078	JM23000066	LOCK SPRING	1	
079	JM23000067	SHAFT LOCK	1	
080	JM23000068	COVER	1	
081	JM23000030	FLAT WASHER5	2	
082	JM23000031	SPRING WASHER5	2	
083	JM23000069	PAN HEAD SCREW M5 X 12	2	
084	JM23000070	FLAT WASHER16	1	
085	JM23000071	ANTI-LOOSE NUT16	1	
086	JM23000072	SAFETY COVER COMP.	1	
087	JM23000073	TORSION SPRING	1	
088	JM23000074	SQUARE NECK BOLTM6X10	1	
089	JM23000075	WHEEL	1	
090	JM23000076	E RING	1	
091	JM23000077	STEPPED BOLT M6	1	
092	JM23000078	RUBBER SLEEVE	1	
093	JM23000079	FIX PLATE	1	
094	JM23000080	ANTI-LOOSE NUTM6	1	
095	JM23000081	STEPPED BOLT M5	1	
097	810964-8	CAUTIONLABEL	1	
098	JM23080042	NAME PLATE	1	
099	JM23000084	SPINDLE	1	
100	JM23000085	KEY5X10	1	
101	JM23000086	BALL BEARING 6304-RZ	1	
102	JM23000087	SPACE RING 20	1	
103	JM23000088	HELICAL GEAR	1	
104	JM23000089	SPACE RING 16	1	
105	JM23000090	PAN HEAD SCREW M6	1	
106	JM23000091	GEAR HOUSING COMP.	1	
107	JM23000092	PAN HEAD SCREW M5 X 20	1	
108	JM23000093	LIMIT PLATE	1	
109	JM23000094	LIMIT PAD	1	
110	JM23000095	ADJUST PAD	1	
111	JM23000096	HEX.NUTM4	6	
112	*****	*****	***	*****
113	JM23000098	FAN GUIDE	1	
114	JM23000099	BALL BEARING 6201Z	1	
115	JM23000100	ARMATURE ASS'Y (230V)	1	
		INC. 114,117		
116	JM23000101	SELF TAPING SCREWST4.8X70	2	
117	JM23000102	BALL BEARING 6001Z	1	
118	JM23000103	RUBBER RING	1	
119	JM23000104	FIELD ASS'Y (230V)	1	
		INC. 120		


SPARE PARTS LIST

MODEL NO. MT230

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
120	*****	*****	***	*****
121	JM23000106	SELF TAPING SCREWST4.2X12	2	
122	JM23000107	STRAIN RELIEF	1	
123	JM23000156	POWER SUPPLY CORD	1	
124	JM23000109	CORD GUARD	1	
125	JM23000110	NOISE SUPPRESSOR	1	
126	JM23000111	CLAMP	1	
127	JM23000112	SWITCHCB21-B	1	
128	JM23000113	SELF TAPING SCREWST 3X8	2	
129	JM23000114	SWITCH LEVER	1	
130	JM23000115	SELF TAPING SCREWST4.2X12	2	
131	JM23000116	TERMINAL BASE	1	
132	*****	*****	***	*****
133	JM23000118	PAN HEAD SCREW M4X30	6	
134	JM23000119	SELFTAPPING SCREW	1	
135	JM23000120	BRUSH HOLDER CAP	2	
136	JM23000121	BRUSH HOLDER	2	
137	JM23000122	HEX. SOCKET HEAD BOLT M5 X 8	2	
138	JM23000123	CARBON BRUSH	1	
139	JM23000124	SELF TAPING SCREWST5.2X12	2	
140	JM23000125	MOTOR REAR COVER	1	
141	JM23000126	WING BOLT	1	
142	JM23000132	BRACKET	1	
143	JM23000133	LOCK LEVER	1	
144	JM23000134	SPRING	1	
145	JM23000135	SCREW M5	1	
146	JM23000136	FLAT WASHER4	2	
147	JM23000137	SPRING WASHER4	2	
148	JM23000138	PAN HEAD SCREW M4 X 8	2	
149	JM23000139	ANTI-LOOSE NUTM5	1	
150	JM23000030	FLAT WASHER5	1	
151	JM23000183	CAPACITOR	1	
152	JM23000185	KNOCK SPRING CAP	1	
153	JM23000005	KNOCK SPRING	1	
A01	JM23000127	HOLDER SET	2	
A02	JM23000128	SET PLATE	2	
A03	JM23000129	WING BOLT	1	
A04	JM23000130	WRENCH	1	
A05	JM23000131	WISE ASS'Y	1	
A06	*****	*****	***	*****
A07	762001-3	TRIANGULARRULE	1	
E01	JM23010001	SUB FENCE COMPLETE	1	
E02	JM23000201	COUNTERSUNK HEAD SCREW M6X25	1	
E03	JM23100110	LOCKNUT M6	1	
E04	JM23000202	FIX PLATE	1	
E05	JM23100033	CROSS HEAD SCREW M4X12	1	
E06	JM23000137	SPRING WASHER4	1	
E07	JM23100071	THIN FLAT WASHER 6	1	

SERVICE DRAWING

MODEL NO. MT230



SERVICE DRAWING

MODEL NO. MT230

96

